

# QwikCamp

## RV Sewer Connection Kit Installation Guide

### Kit Includes

- Gate Valve Bushing
- 3-in-1 Slip-Fit Sewer Cleanout Adapter
- 4" x 3" Gate Valve Adapter
- 3" x 3" Flexible Coupling
- 90° Elbow
- Pipe Cap

### Supplies Needed

- Hand Saw
- 5/16" Nut Driver, Screwdriver or Impact Driver
- Utility Knife
- 3" x 10' SCH 40 PVC Pipe (2 pieces)
- Pipe Stands



### Step 1

Position the RV where the drain outlet is near the sewer pipe.



### Step 2

Install the gate valve bushing onto the RV drain by aligning each opening with the tabs of the bayonet fitting.



### Step 3

Install the larger end of the 4" x 3" gate valve adapter onto the bushing and tighten the band securely. **DO NOT** overtighten.



### Step 4

Slide the slip-fit adapter into the sewer outlet.



### Step 5

Lay out the PVC pipe in relation to where the RV and sewer outlet are located.



### Please Note

For longer runs, use the included 3" coupling to connect additional pieces of pipe.



Scan the QR code to watch the installation video or learn more about QwikCamp.

# QwikCamp

RV Sewer Connection Kit Installation Guide



## Step 6

Measure both sections of the pipe using the end of the coupling socket as a guide.



## Step 7

Cut each piece of pipe with the saw and deburr with a deburring tool or utility knife.



## Step 8

Connect the pipe from the RV drain outlet to the 90° elbow and fasten the hose clamp.



## Step 9

Connect the pipe from the 90° elbow to the 3" coupling or the QwikCamp sewer adapter.



## Step 10

Add support blocks under each connection point to aid flow. Inspect for leaks.

## Need assistance?

For further questions, please contact Fernco Customer Service at (810) 503-9000



www.fernco.com

ES092022